

# Grozone Control

## CO2R / SCO2 / CO2D Alarm and Error Meanings

Alarm / Error #	Description	Displayed on Screen
Error 1	<b>CO2 Sensor problem:</b> turn power off and retry. If problem persists, call your retailer.	CO2 and SCO2: « <b>Er. 1</b> » CO2D: «----»
Error 3	<b>Real Time Clock problem (CO2D only):</b> turn power off and retry. If problem persists, call your retailer.	« <b>Er.3</b> » Alternately with sensor values
Error 8	<b>Memory corruption problem:</b> all settings have been reset to factory settings. You may need to re-enter your settings. If problem persists, call your retailer.	« <b>Er.8</b> » Alternately with sensor values

## Significations des alarmes et erreurs CO2 / SCO2 / CO2D

No Alarme / erreur	Description	Affichage à l'écran
Erreur 1	<b>Problème du capteur de CO2 :</b> Déconnecter le contrôleur et rebrancher. Si le problème persiste, appelez votre magasin.	CO2 et SCO2: « <b>Err1</b> » CO2D: «----»
Erreur 3	<b>Problème avec l'horloge.</b> (HTC seulement). Déconnecter le contrôleur et reconnecter. Si le problème persiste, appelez votre magasin.	« <b>Er.3</b> » alterne avec les valeurs des capteurs.
Erreur 8	<b>Corruption de la mémoire.</b> Tous les paramètres ont été réinitialisés avec les valeurs initiales par défaut. Vous pouvez avoir besoin de reprogrammer votre contrôleur. Si le problème persiste, appelez votre magasin.	« <b>Er.8</b> » alterne avec les valeurs des capteurs.